



## INSTALLATION

USE GRAB BAR BRACKET AS TEMPLAT TO DRILL  $21/64$  HOLES IN TOP OF RIB. INSTALL RIVNUTS WITH TOOL SUPPLIED IN KIT. BOLT THE BRACKET IN PLACE AND LOCATE THE TWO CLIP ANGLES ON ANOTHER RIB IN FRONT OF THE BRACKET AND INSTALL RIVNUTS. BOLT CLIP ANGLES IN PLACE. INSTALL BRACE BANDS ON TOP OF BRACKET AND DETERMINE HOW LONG TO CUT THE ANGLE BRACES FOR CORRECT LENGTH. DRILL  $1/4$  HOLES IN THE ENDS OF ANGLE BRACES THAT HAVE BEEN CUT. BOLT ALL ITEMS IN PLACES AS ILLUSTRATED IN DIAGRAM.

## GRAB BAR KIT

#141G2	- 1/4X1 HXHDPCS GR2 ZP NC 11REQ'D
#14FW	- 1/4 FLAT WASHR ZP 15REQ'D
#14NI	- 1/4 NYLON INSERT NUT 4REQ'D
#14RIV	- 1/4 RIVNUT ALUM. 7REQ'D
#158PST	- 1-5/8 BRACE BAND ZP 2REQ'D
#AB1X24	- ANGLE BRACE 1X1X20LONG 2REQ'D
#CL112	- CLIP ANGLE 1-1/2X2X1-5/8 2REQ'D
#GGB	- GRAB BAR BRACKET 1REQ'D
#GRAB	- GRAB HANDLE 1REQ'D
#RIVTOOL	- 1/4 RIVNUT TOOL 1REQ'D