

ROCK GUARD INSTALLATION

CAVITATION PLATE

ROCK GUARD FIN

1. CLAMP ROCK GUARD FIN
IN PLACE PARALLEL TO THE
CAVITATION PLATE.

2. CENTER PUNCH THROUGH
THE HOLES THEN REMOVE
ROCK GUARD FIN.

3. DRILL HOLES THROUGH
THE SKEG WITH A 5/16
DRILL BIT.

4. INSTALL KIT WITH BOLTS
PROVIDED. (2-5/16 X 3/4
GRADE 5 BOLT & 2 NYLON
INSERT NUTS)

