

TINY TACH INSTALLATION

For Tiny Tachs to function correctly they need to be installed with the procedure listed below.

1. Attach the Tiny Tach to your motor with the supplied rivets and attach the ground clamp (white wire) to a suitable ground.
2. Wrap the red wire around a spark plug wire with **only two wraps**. Make one wrap around the red wire to hold it in place and cut off the excess red wire. If you have multiple wraps around the spark plug wire, the tach will not read correctly and possibly malfunction completely.

